



SEATTLE  
**makers**

**Tool:** Palm Sander

**Model:** Dewalt DWE6411K

**Location:** Woodshop

## Safety Instructions for All Tools

### Wear proper apparel

- Always wear eye, ear and respiratory protection. Do not wear loose clothing, gloves, neckties, rings, bracelets or other jewelry which may get caught in moving parts. Non-slip footwear is recommended. Wear protective hair covering to contain long hair.

### Keep work area clean and check for damaged parts

- Cluttered areas and damaged tools invite accidents.

If you have a question, ASK FOR HELP!

## Safety instructions: Palm Sander

### **Purpose of the tool**

- A palm sander is a type of electric sander that uses traditional sandpaper and vibrates in a circular pattern.

### **Setting up the tool**

- Prior to using the sander, ensure that it is disconnected from the power supply.
- Attach the proper sand paper grit and lock it in place.
- Ensure that your material is resting on a stable work surface.
- Connect the sander to the power supply.

### **Operating the tool**

- Place the sander on your material and turn on the power.
- Move the sander around your work material, ensuring constant movement to avoid marring the surface.
- Do not force the sander on the material or else the sander, the sandpaper or your material may break, causing injury.
- Turn off the power when you are finished sanding.

### **Storing the tool**

- Disconnect the sander from the power supply.
- Clean off any debris or saw dust left on the sander.
- Replace the sander and sandpaper in their storage locations.